



INSTALLATION OF CABINET

1. Insert the (4) mounting tabs fully into back box mounting tab slots, use rubber mallet if necessary.
2. Select location, place cabinet in closed position, against the wall, mark holes. Remove cabinet.
3. Drill (4) 1/4 in. diameter holes. Insert the (4) #10-12 wall anchors.
4. Place cabinet in position. Install the (4) #10 x 1 1/2 in. screws.

INSTALLATION OF SHELF

1. Align wire shelf to bottom mounting posts inside the cabinet.
2. Insert (2) #8-32 x 1/2 in. machine screw, through #8 washer, into mounting post and tighten.

⚠ WARNING: This product can expose you to chemicals including Dichloromethane, which is known to the State of California to cause cancer, and Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at www.sti-usa.com/wc14.

INSTALLATION OF STI-7531MED CABINET WITH WIRE SHELF

All specifications and information shown were current as of publication and are subject to change without notice.