



**INSTALLATION INSTRUCTIONS**

1. Center protective cover over thermostat.
2. Using protective cover as template, mark and drill (6) 3/16 in. (4.7mm) diameter holes as shown.
3. Install the tamperproof fasteners using the supplied spanner bit.

**CLEANING INSTRUCTIONS**

To clean cover, remove from wall. Rinse with water to remove abrasive dust and dirt. Wash with soap or mild detergent using a soft cloth (DO NOT SCRUB). Rinse once more, then dry with a soft cloth or chamois. To remove grease or wet paint, rub gently with a cloth wetted thoroughly with naphtha. Then wash and rinse. DO NOT USE RAZOR BLADES.

**WARNING:** This product can expose you to chemicals including Dichloromethane, which is known to the State of California to cause cancer, and Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at [www.sti-usa.com/wc14](http://www.sti-usa.com/wc14).



**STI-9115 & STI-9116 TAMPERPROOF THERMOSTAT COVERS**  
All specifications and information shown were current as of publication and are subject to change without notice.

9116IS APR2022

