



VIEW IN DIRECTIONS OF ARROW **D**

INSTALLATION INSTRUCTIONS - REFER TO EXPLODED VIEW

1. Remove the backing paper from the gasket and attach it to the back of the hub.
2. Select the location on the back box where conduit hub is to be mounted.
3. Align the center of holes A & B directly on intersection line C.
4. Using a pointed tool, mark a center point in the center of holes A & B on the intersection line C.
5. Drill three (3) holes: Hole A 7/32 in. diameter, Hole B 1/2 in. diameter.
6. Complete installation as shown.

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at www.sti-usa.com/wc14.



INSTALLATION OF KIT-6297B20 CONDUIT HUB ASSEMBLY

All specifications and information shown were current as of publication and are subject to change without notice.