



### INSTALLATION INSTRUCTIONS

1. The (6) mounting holes must be marked and drilled with the (6) anchors installed prior to the installation of the G70496 gasket.
2. After the G70496 gasket is installed the G70495 gasket (if needed) may now be placed around conduit.
3. Place G70498A gasket into the groove on the bottom side of cover and complete installation as shown.

Three year warranty or a one year limited warranty  
(from date of purchase) on most products. See website for details.  
Electronic warranty form at [www.sti-usa.com/wc14](http://www.sti-usa.com/wc14).

### KIT-123 ENVIRO-KIT

All specifications and information shown were current as of publication and are subject to change without notice.

KIT-123IS JAN 2000

