



VENT	A	B	C	VENT HOLE CUT SIZE
KIT-REV80	3.94 in. (100mm)	4.07 in. (103mm)	1.45 in. (37mm)	3.50 in. diameter (89mm)
KIT-REV60	2.91 in. (74mm)	3.02 in. (77mm)	1.23 in. (31mm)	2.50 in. diameter (64mm)

INSTALLATION INSTRUCTIONS

1. Cut vent hole into enclosure per vent hole size.
2. Place vent in hole.
3. Install nut onto thread.
4. Hand tighten until gasket is slightly compressed and vent is secure.



KIT-REV60, KIT-REV80 EnviroArmour® Series Vent

All specifications and information shown were current as of publication and are subject to change without notice.