



#### INSTALLATION INSTRUCTIONS

1. Center the cover over existing display.
2. Mark and drill (12) holes. When using plastic anchors, drill 3/16" diameter hole, 1-1/4" deep. Without plastic anchor, drill 7/64" diameter hole 1-1/4" deep.
3. Insert screw thru neoprene washer, then thru cover to mounting surface.  
Do not overtighten as cracking may occur, especially on uneven surfaces.

Material: Clear UV Stabilized PETG  
Thickness Approx: 0.125 in. (3mm)

#### CLEANING INSTRUCTIONS

1. Gently blow away any loose dust or dirt.
2. Wash with soap or mild detergent using a non-abrasive, lint-free cloth. (Do not use window cleaning fluids with ammonia such as Windex®)
3. Rinse well with clean water.
4. Blot dry with a soft cloth or chamois to avoid water spots.
5. To remove grease, oil and tar, rub gently with a cloth wetted thoroughly with naphtha, and quickly wash and rinse to prevent damage.  
(DO NOT USE RAZOR BLADES.)

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details.  
Electronic warranty form at [www.sti-usa.com/wc14](http://www.sti-usa.com/wc14).



### STI-VFC01 VACUUM FORMED COVER

All specifications and information shown were current as of publication and are subject to change without notice.