



### INSTALLATION NOTES

1. With shield rotated to open position (approximately 90° to shell), insert shield pivots into slots on Stopper Station shell.
2. Rotate shield to closed position.
3. Mount shield and shell onto Stopper Station contact assembly.
4. Install screw to hold shell to contact assembly.

**WARNING:** This product can expose you to chemicals including Dichloromethane, which is known to the State of California to cause cancer, and Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at [www.sti-usa.com/wc14](http://www.sti-usa.com/wc14).



USA

### STI-6517 STI STOPPER® STATION SHIELD

All specifications and information shown were current as of publication and are subject to change without notice.

6517IS MARCH2010



EMEA