



INSTALLATION INSTRUCTIONS

1. Remove push button actuator assembly.
2. Align actuator cap to push button actuator.
3. Align 2" button slots to tabs on push button actuator.
4. Snap 2" button onto push button actuator and rotate right to lock.
5. Insert spring into push button actuator.
6. Squeeze legs of push button actuator and align into die cast plate.

⚠ WARNING: This product can expose you to chemicals including Dichloromethane, which is known to the State of California to cause cancer, and Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at www.sti-usa.com/wc14.

INSTALLATION OF UB-2LENS 2" LENSES FOR UNIVERSAL BUTTON

All specifications and information shown were current as of publication and are subject to change without notice.